





















Accessories Wöhler VIS 700 HD-Cable camera		Article no.
	<b>Guidance Set 100</b> for camera head Ø 40 mm	4240 J
	<b>Wöhler Viper L 20 m</b> Scope of delivery: push rod 9 mm, 20 m long, 2 stainless steel end pieces M10, star holder, projection tube 80 cm long (without stars or brushes)	9413 I
	<b>Camera holder</b> for Wöhler VIS 700 Faces down, cleaning rod or viper necessary for pushing	7068 J
	<b>Wöhler Camera Spring Guide</b> for camera head Ø 40 / 51mm for centering of the camera head in vertical vents	7081 J
	<b>Protection Sleeve</b> for Wöhler Camera Head Ø 40 mm with cut-out	2641 J
	<b>Replacement Plastic Domes (10 pcs.)</b> for Wöhler Camera Head Ø 40 mm	3675 J
	<b>Glass Dome</b> for Wöhler Camera Head Ø 40 mm	3674 J
	<b>VIS Centering Brush</b> Ø 20 cm for all camera rods, can be fixed directly behind the camera head	3850 J
	<b>Camera Roller Guide</b> suitable for camera heads and rods	3681 J
	<b>VIS Spare Brushes</b> for centering brush, 24 pieces	3858 J
	<b>Centering Brush</b> Ø 20 cm for all camera rods, can be fixed at any position of the camera rod	3854 J
	<b>Centering Brush Extension</b> Ø 20 cm for Wöhler VIS 2xx / 3xx / 400 / 700 (detachable versions) to extend centering brush art. 3854	3853 J
	<b>Stabilization Tube</b> for Wöhler VIS 2xx / 3xx / 400 (detachable versions) to connect centering brush art.3854 & extension art. 3853	21736 J
	<b>Guidance Ball</b> for flex part of camera push rod, improves ability to go through bends	3634 J
	<b>Wöhler VIS Camera Trolley</b> Scope of delivery: Wöhler VIS Camera Trolley, Camerahead-holder, Storage bag Wöhler VIS Camera Trolley for inspection of pipes > 150 mm	4705 J
	<b>Wöhler L 200 Locator (Receiver)</b> Scope of delivery: Wöhler L 200 Locator Receiver, plastic case, USB power supply with micro USB cable, grease crayon (12 pcs. box, yellow), telescopic rod and headphones	7430 J
	<b>Wöhler VIS Cleaning Set</b> 1 liter disinfection spray, 50 cleaning tissues, 100 disposable gloves size XL (powder free), 200 ml lubricant, plastic case, for approx. 50 applications	4725 I
	<b>Wöhler VIS Cleaning Set Refill</b> 1 liter disinfection spray, 50 cleaning tissues, 100 disposable gloves size XL (powder free), 200 ml lubricant, in plastic bag, for approx. 50 applications.	4726 O
	<b>Wöhler HD-Camera Head Ø 26 mm</b> colour, detachable and digital with leather protection bag	7613 J
	<b>Wöhler Guidance Set 70</b> for camera head Ø 26 mm guidance sleeve with protection cage (Article no. 3847), centering brush (Article no. 3850)	3883 J