

## HC2 simulators

### FEATURES

- Humidity / Temperature simulators with fixed values and certificate
- For system validation
- Values cannot be changed with the HygroSoft software
- Range of application: -40...100 °C

Service cables		
Order code	Humidity	Temperature
HC2-SIMC-000/0023	0 %RH	23 °C
HC2-SIMC-035/0023	35 %RH	23 °C
HC2-SIMC-050/0023	50 %RH	23 °C
HC2-SIMC-080/0023	80 %RH	23 °C

Other types available on request.



## Protective caps

### FEATURES

- Protects probes/connectors during cleaning cycles against water and chemical substances, e.g. H<sub>2</sub>O<sub>2</sub>

Protective caps	
Order code	Protection
Protection-E2/E3	Connectors
Protection-Filter	Sensor note: only compatible with HC2 probes
Protection-HC2	Complete HC2A/HC2 probe



Protection HC2


Protection filter



Protection E2/E3

## Mounting kits

Mounting kits	
Order code	Description
AC5002	DIN top-hat rail adapter for PF4, PF5, HF4, HF5, HF8



AC5002